

São Paulo - 20 de Março, 2013.


ATESTADO DE CAPACIDADE TÉCNICA

Para os devidos fins, atestamos que a empresa TRICOMEX LTDA – EPP, inscrita no CNPJ nº 14.027.036/0001-73, com endereço na Av. Maurílio Biagi, 800 – sala 811, Bairro Santa Cruz do Jose Jacques – Ribeirão Preto, SP/Brasil, nos forneceu os itens a seguir:

- 05 pçs. válvulas esfera FF DN500 com posicionadores eletropneumáticos;
- 06 pçs. válvulas guilhotina FF DN500 e 11 pçs. medidores eletromagnéticos de vazão DN500.

Ressaltamos que a TRICOMEX cumpriu satisfatoriamente o prazo de entrega, instalação dos itens e entrega das documentações técnicas.

Atenciosamente,


GABRIEL GODOY
Gerente Comercial
BARRIQUAND DO BRASIL
12.448.147/0001-28


1º TABELÃO DE NOTAS - RIBEIRÃO PRETO
SILVIA M. COLAVITA PAPASSIDERO - TABELÃO
AV. NOVE DE JULHO, 1189 - HIGIENÓPOLIS - CEP 14015-170 - FONE/FAX: (16) 3977-7080
Reconheço por semelhança a(s) firma(s) de: **GABRIEL ALVES GODOY (240300)**, do que dou fé
Ribeirão Preto - SP, 11/10/2013. Total das Firmas: R\$ 4,25
MARILUCI BIR SEBASTIANI - ESCRIVENTE AUTORIZADA
ATENDENTE: **MARILUCI BIR SEBASTIANI - ESCRIVENTE AUTORIZADA**
Segurança: 4947424857484951494857424851
SELO: 270794
"VALIDO SOMENTE COM O SELO DE AUTENTICACAO SEM MANCHA E SEM RASURAS"
1º Tabelão de Notas
de Ribeirão Preto - SP
Mariluci Bir Sebastiani
Escritor
0880AA270794

BARRIQUAND DO BRASIL
Av. Anhanguera 484, Ribeirão Preto, SP
Fone / Fax: (16) 3421-5145 / 3421-5135
www.barriquand.com.br

1º Tabelão de Notas
de Ribeirão Preto - SP
Caroline Sant'Ana
Escritor



0880AC029292

1º TABELÃO DE NOTAS DE RIBEIRÃO PRETO
SILVIA M. COLAVITA PAPASSIDERO - TABELÃO
Av. 9 de Julho, 1189 - CEP: 14015-170
FONE/FAX: (16) 3977-7080

Rib. Preto 11 OUT, 2013

AUTENTICACÃO

Autentico a presente cópia extraída
neste tabelionato do respectivo original, dou fé.
Valor recebido por autenticação R\$ 2,50

DECLARAÇÃO DE CAPACIDADE FABRIL

A Licitante TRICOMEX LTDA - EPP, CNPJ nº 14.027.036/0001-73, por seu representante legal abaixo assinado, declara, sob as penalidades da lei, que a NMM&CI (Nanjing Metran Measurement & Control Instrument Co. Ltd.), fabricante dos medidores de vazão eletromagnéticos, tem a capacidade fabril para executar a fabricação dos equipamentos do Pregão 69/2013 (Grupo V), de acordo com os detalhes a seguir:

1. Endereço da empresa

Nanjing Metran Measurement & Control Instrument Co. Ltd. localizada em No.12 Rungu road, Guli Industrial Zone, Jiangning district, Nanjing City, PR.China,

2. Área total da Fábrica incluindo almoxarifado (separado)

Área total da fabrica 1500 m2 e de almoxarifado 150 m2.

3. Área total de Administração

200 m2

4. Maquinários instalados

Maquina de dobra para chapas de metal

Maquina de corte tipo Plasma

Equipamento de calibração de vazão

CLP Controlador Logico Programável

Maquina de serra para tubos

Ribeirão Preto, 08 de Outubro de 2013.




Maximiliano Ludewig
Diretor - TRICOMEX Ltda.
Cel. +55 16 99105-8599
ml@tricomex.com

TRICOMEX LTDA.

Av. Maurilio Biagi 800, 8º andar - sala 811 - CEP 14020-750 - Ribeirão Preto, São Paulo - Brasil
Tel.: +55 (16) 3234-7799 Fax: +55 (16) 3234-7430 website: www.tricomex.com


P4E 29 -



Electromagnetic flowmeter

Manual

NANJING METRAN
MEASUREMENT & CONTROL INSTRUMENT CO.,LTD

Dear Users:

Thank you for choosing METRAN electromagnetic flow meters. Please read this manual carefully before using, to make sure the product in proper installation and use, and achieve its best performance.

Encountered any problems in the course of usage, please contact us in time.

Unauthorized repair or replacement of spare parts resulting in product performance failures and damages, we will not undertake any responsibility.

2005.3.20


Contents

I Introduction	1
1. Measuring principle	1
2. Main technical parameters	2
II Installation	3
1. Pipeline design	3
2. Installation requirements	4
3. Mechanical Installation	6
4. Dimensions	7
5. Electrical wiring	9
III Parameter settings	10
1. Inverter Panel	10
2. Local operations	11
3. Inverter Settings	23
IV Instrument detection and maintenance	29

I Introduction

1、Measuring principle

The principle of the sensor is based on Faraday's law of electromagnetic induction. Shown in Picture 1



Picture 1 Working principle

It is installed a pair of detection electrodes on the pipe wall, where the measurement pipe axis and magnetic field lines are vertical. When the conductive liquid cuts magnetic field lines and produces induced electromagnetic force, which can be measured by the two electrodes on the meter pipe. The result can be calculated by formula:
Induced electromotive force, (flow signal)

$$E = KBV$$

式中：E—Induced electromotive force, V;

K—meter constant;

B—Magnetic flux density, T;

D—Internal diameter of measuring pipe, m;

V—Average velocity of pipe section, m/s.

Assume the volume of liquid as $qv(m^3/s)$, $qv = \pi D^2 V / 4$, so in the formula $E = (4KB/\pi D) qv = Kqv$, K is meter constant, $K = 4KB/\pi D$.

104

ually, the electromagnetic flow meter consists of two parts, transmitter and sensor, the measuring electrodes inspect the electromotive force, and transmit to the converter, the converter pres excitation current.

is usually called a flow signal, after processing the flow signal by inverter, output 4~20 mA\ pulse(or frequency) signal which is proportional to the flow rate, then the flow rate recording, adjusting can be achieved.

2 Main technical parameters

- Ambient temperature: -25°C~+65°C
- Ambient humidity: $\leq 95\%$
- Medium temperature: -25°C~+80°C (Note: The temperature is different for each lining material, please advise when place order.)
- Working protection level: IP65、IP67、IP68
- Flow range: 0.5 --- 15m/s
- Measuring diameter: DN10---DN2400
- Electrode material: Standard 316L (other material is optional)
- Flange installation: Comply with GB9119, carbon steel (stainless steel is optional)
- Pressure Grade: PN1.0; PN1.6; PN2.5; PN4.0 optional
- Accuracy Grade: 0.5 Grade、0.2 Grade
- Measuring Parameters: instant flow、instant flow rate
- Record parameters: Total flow accumulated, 32 group event record
- Detection and alarm parameters: Pipe empty alarm, Excitation current detection alarm
- Battery capacity detection alarm
- Flow curves: Automatically show flow percentage and curves.
- Alarmed output signal: Unit volume flow pulse

- Wireless communication : None (According to customer requirements)
- Power supply: 24V DC
110V AC、220V AC

II Installation

1、Pipeline design

Pipeline design should consider the following conditions:

(1) Location

The installation location of the flow meter should consider substantial changes in the ambient temperature, away from direct sunlight. If the ambient temperature does not meet the requirements, please consider insulation ventilation processing or thermal treatment.

Avoid strong corrosive atmospheric environment and containing explosive gas location.

(2) Avoid magnetic interference

Do not install the flow meter to the place where is easy caused electromagnetic interference, such as motor, inverter, transformer or other power equipment, power source nearby.

(3) Length of straight pipe

In order to ensure measuring accuracy, please ensure that the flow meter upstream straight pipe length is at least 5 times (5D) than the pipe diameter, downstream straight pipe length is at least 2 times (2D) than the pipe diameter.

(4) Maintenance space

The flow meter installation location, should fully consider to allow sufficient space for maintenance.

(5) Adopt throttle valve and the bypass valve

Adopt throttle valve and the bypass valve for easy maintenance and zero adjustment.





(6) The support of the flow meter

Do not install the flow meter alone on the free vibration pipe, should be equipped with a support base that holds the measuring tube. When the flow meter is installed underground, inlet and outlet of the flow meter should be installed supports, the top of the flow meter should install metal protection plate.

2. Installation requirements

(1) Sensor installation

In order to avoid the attached gas caused measuring error, damage the lining by vacuum, please refer to the following installation diagram



(2) Sensor grounding

In order to make instrument work reliable, to improve measuring accuracy and stability, free from outside interference from parasitic potential, sensors should have a separate grounding wire, if the grounding wire is coated with insulating layer or non-metallic pipes, on both sides of the sensor should also be equipped with grounding rings.

① Grounding ring

A: Common Ground Ring

Material: Optional

Thickness: 3mm—12mm

Sensor with PTFE or rubber lining is fixed by a screw on the flange, to protect the lining flanging from damage.

B: Hubbed grounding ring


Material: Optional

Thickness: 3mm


bed grounding ring is usually for the abrasion resistance
 rim, it can protect the lining of the measuring tube end. Extend
 the of the sensor.

Grounding method

The sensor is installed on the metal pipe: pipe without
 lining coating.




A: Grounding method: copper wire
 2: Insulating grounding wire



B: Grounding method: copper wire
 2: Insulating grounding wire
 3: Grounding flange and grounding wire

B: The sensor should be installed in the plastic pipe or the
 re which inner wall with insulating coating.



1: Grounding with Normal copper wire
 2: Insulating grounding wire
 3: Grounding flange or grounding ring must be installed with pipe flange
 4: Connection wire (copper cross sectional area > 2.5 square mm)
 sensor high voltage protection potential

3 Mechanical Installation

(1) Pipeline installation

1. Before installing flow meter, please calibrate pipeline, to
 ensure that the flow meter and pipe have a better concentricity.
2. Before installing the flow meter, please clean the pipeline
 to avoid the debris (such as: welding slag) damage the flow

meter lining, while the debris will affect the accuracy of
 measurement.

(2) Flow meter installation


1. While installing flow meter, the medium flows direction must
 be the same with the flow meter label identifies.
2. To connect the flow meter flange with pipe flange via bolts,
 and check the tightness of the bolts in the day-to-day maintenance,
 to prevent loosening caused media leaks or other damage.

(3) NOTES


1. Do not open during the transportation, when unpacking,
 please be careful not to damage the instrument. Large diameter
 flow meter please using hoisting rings.
2. After unpacking the instrument, please protect the liner
 surface, the liner surface can not be placed on the ground or
 other work sites.
3. After wiring, check the screws are tightened, to ensure the
 sealability of the junction box.
4. If the instrument is not in use for a long time, please close
 both ends of the sensor, placed in ventilated and dry place, to
 ensure that moisture and water can not enter the inside of the
 instrument, and check it regularly.

4. Dimensions


(1) Sensor size



(2) Converter Dimensions



Compact type appearance



Remote type appearance

5. Electrical wiring

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
DS	A	C	B	DS	X	Y	+	-	+	-	Aux	Bit	L	+	-	+	-	K21	K22	~	FG	~
input					excitation						output							communication	measurement	control		power supply

Remote type Electrical wiring

2	3	4	5	6	7	8	9	10
	1		A	B	L	12		
input	Frequency		RS-485			AC 220V		
output			communication			power supply		

Compact type Electrical wiring

Parameter settings

1. Inverter Panel

Key	Name	Function
	Flip	Flip, back display, view setting record
	Right shift	Move the cursor, View statements and power off records.
	Increase	Setup increase, single-screen display instantaneous flow rate.
	Confirm	Set confirm and enter the main screen, zero calibration.

2. Panel Description

Press "confirm" to display the main screen, if there are spool blocks of L, H, T, P, appears at the bottom right corner of "Frate", representing L: the flow rate is lower than the lower limit vaof resection, H: flow rate is higher than upper limit value T: erripte alarm, P: Poor grounding signal.

Press "right shift" for 3 seconds, the meter enters the query stacan be selected for the "Daily", "Monthly", "Annual "Report", "pc cut" menu, through "right shift" and "increase" button, can fligge to view corresponding statements and blackout records, prethe "flip" key to exit the menu.

3. Panel Operation

3.1 Continuous press Page, can show the following picture:

◆Flow

Singal screen can show instant Flow, flow rate, and total flow.

Get back to this screen by pressing button.

Inst	13.006m ³ /h
Flow	7.5000m/s
Accu	00000878m ³

◆Instant flow

Single screen can show instant flow, flow rate and percentage. Can go Back the interface fast by pressing Button

Instant	7.5m/s
13.006	m ³ /h
	26%

◆Total flow

Single screen display forward total Flow, shadow part is decimal placeCan reach this screen by pressing button.

+Total m ³
00000884



Sir screen shows forward ,backward and difference total. If flow dirn set, negative flow shut off, then this screen shut off.

Total	
+00000881	m ³
-00000001	m ³
T	+00000880 m ³




Sir screen shows output signal ,Output current and frequency vaalternatively. Also shows sensor diameter and measure range.

Output	650.20Hz
Diameter	25.000mm
Range	100.00m ³ /h




Sir screen shows current date And time.

12-03-16
09:15:20




Sir screen shows power off times, and total power off time. it cacord 20 times of power off.

Power off records	
Number	015 times
Accu	000120 minutes




Flow curve
Single screen shows instant flow, Flow rate, flow curve, flow percentage, output current and frequency value.



Communication
Single screen shows communication Status, IP address, baud rate.

Comm status:	Nor	HH
Local host:	001	
Baud rate:	4800n1	

3.2 Inquiry



Pressing the continuously for 3 second, can enter inquiry menu, you can choose daily report, monthly report, yearly report and power off menu, press to inquiry, press button to exit this inquiry menu.

◆Water report

By button and button, Can choose and set the inc of year and month. After confirm, you can check, button can check in reverse order, press button to check in sequence order, press button to quit this menu. can check record for 365 days.

12-04	Daily report
01D	00000000m ³
02D	00000000m ³
03D	00000000m ³

◆Monthly report

Press button and button to Select and set the year. After confirm can check monthly Report. button can check in reverse order, Press button to check in sequence order, press button to quit this menu. can check record for 48 months.

12Y	Monthly report
10M	00000000m ³
11M	00000000m ³
12M	00000000m ³

◆Daily report

Press button and button to Select and set the year. After confirm can check daily Report. button can check in reverse order, Press button to check in sequence order, press button to quit this menu. can check record for 5 days.

12Y Yearly report
00967295 m³

12Y Monthly report
10M 00000000m³
11M 00000000m³
12M 00000000m³

◆Power off

Press button and button to can check power off record. Press button can check in reverse order, Press button to check in sequence order, press button to quit this menu. can check record of 18 times.

Power off records	
01.	09-08-30 08:03 v
	09-08-27 11:15 x
02.	09-08-27 07:37 v
	09-08-26 20:24 x
03.	09-08-26 19:14 v
	09-08-26 07:43 x

◆Fixed record

Press the button for 3 seconds, Enter setting record menu. This page records the parameter Setting times and the date and time for the last setting record.

12Y Monthly report
10M 00000000m³
11M 00000000m³
12M 00000000m³

3.3.1rm

On screen of flow, if under "flow rate" Appears the letter of T、P、X、H, It means : T: empty alarm; P: poor grounding signal; X: itation alarm; L: flow rate lower than cut-off value; H: flow ratger than up limit.

Setting record

Time: 12-12-06 13:36
Number: 019 times

Inst 13.006m³/h
Flow_x 7.5000m/s
Accu 00000878m³

3.4.tting

3.4.1system setting

Be using the meter, set the system by following the menu. Caously pressing CONFIRM Button 3 seconds, system inces to enter password, input correct password. Go to setting me please refer to user manual chapter 10 SYSTEM SETING to finish the settings.

Please enter password

Menu setting
Mode Parameter
System Communication
Alarm

3.4.2 Output

As for frequency, pulse output signal which only comes to effect via the confirmation of instrument output system menu. The instrument support two signal simultaneous output, and the frequency and pulse output signal share one frequency output channel.

3.4.3 Initialization

Connect the wiring to sensor and instruments correctly to ensure reliable grounding. Supply power for about 10 minutes until full pipe situation while the measured liquid is still. Then long press the confirm button for 10 seconds till hearing the bleeping of instrument. It means zero calibration and initialization finished automatically.

3.5 heat type (make note while you order)

Heat type magnetic flow meter is, integrated with flow velocity, heat, accumulation and display, used to measure the water flow rate and temperature difference between water supply and drainage by magnetic sensor and temperature sensor so that to measure and display the water absorbed or released heat while flowing through the power-consumption equipments.

3.5.1 Function

Similar to basic flow type.

3.5.2 Wiring

The wiring is similar to basic flow rate type. Heat type magnetic flow meter has added inlet temperature RT1 and outlet temperature RT2 wire on the basis of basic type corresponding to 15~18 terminal blocks. And normally we adopt PT1000 temperature sensor.

Heat type converter totalizer is restricted to the split type.

3.5 Calibration setting

or the system calibration, it is similar to basic type but heat up/down/high temperature limit and low/high heat output limit ad..

Current, frequency and pulse instantaneous output are according to instantaneous heat output.

the instantaneous output is necessary while calibrating, please set the flow unit in MODE menu then set the heat unit to "off" to take the instantaneous heat output change to instantaneous flame output automatically. When finishing calibration, re-select hermit and change instantaneous flow rate output to instantaneous heat output.

For the temperature sensor, if there is a failure, you can pre-set the instrument via the menu of Factory setting—Fault menu, and the temperature range of fault inlet and fault outlet is 0~150°C. Moreover, the instrument also leaves a inlet temperature irrigation setting function on this menu with a temperature range of ~150°C

3.5.1 Heat monitor

Shows data of flow as well as some relevant value of heat.

◆ **Heat**
Theage shows density, enthalpy difference, instant heat and total.

◆ **Temperature**
Theage shows inlet temperature, outlet temperature, and temperature difference.

◆ **Instant heat**
Theage shows instant heat, and percentage of instant heat.

◆ **Heat**
Theage shows total heat, shadow part is the decimal.

◆ **Curves**
Theage shows instant heat, flow rate, heat curves, percentage of heat's value of current and frequency.

3.6 Protocol measurement type (please make note when you order this type)

Protocol measurement electromagnetic flow meter converter is a meter combine flow, integrating and display, it can measure certain flow according to protocol. For some actual flow, lower or higher than the set value, the meter will automatically measure according to protocol, if the actual flow is within the set flow range, it will measure according to actual flow.

3.6.1 Function

Same function as basic type electromagnetic flow meter

3.6.2 Wiring

Same wiring as basic type electromagnetic flow meter

Protocol measurement type converter only available for remote type/split type

3.6.3 calibration setting

System calibration setting same as basic type.

3.6.4 Protocol measurement

1. Function

◆ Small flow calculation protocol (lower limit)

When actual flow is lower than the measuring lower limit, although the user is having flow (even very small), but the flow meter no output, in the long run it will occur difference of the measuring data. To solve this problem, our meter has the setting of small flow calculation protocol. After negotiation, we set a agreeable fixed value for the lower limit, if the actual flow is lower than this value, meter will show total according to this value. When the flow stops or flow signal lower than the cut-off value, meter will not counter.

◆ Exceeding plan calculation protocol (up limit)

Under certain circumstances, need to control the flow, that is unlimited flow is not allowed, after negotiation, set an agreeable fixed value for up limit, when exceed this set value, the exceeding part multiply a protocol coefficient then counted into the total flow, to realize the function of exceeding plan calculation.

◆ Final calculation protocol (up limit)

In the actual flow value higher than the protocol lower limit or lower than the protocol exceeding plan flow, it belongs to normal flowmeter will show total value according to actual flow.

2. Setting

Enter menu setting- mode- trading, protocol measurement, choose " " and confirm, go to protocol measurement setting, input the protocol coefficient, protocol up limit, protocol lower limit

◆ Protocol coefficient

It the coefficient, range: 0-5

◆ Protocol up limit

It the up limit, range: 0-9999m³/h

◆ Protocol lower limit

It the lower limit, range: 0-9999m³/h

3. m

On screen of flow, if under right side the " instant " appears the left L H, it means L: flow lower than the agreed low limit; H: higher than the agreed up limit.

3. Time division measurement type (please note when place order)

3 division measurement type electromagnetic flow meter meter combines flow, integrating and display, under certain circumstances, meter calculate according to " peak", "Valley", "flat" and the total flow.

3.7 function

It the function as basic type electromagnetic flow meter

3. Wiring

Wiring as basic type electromagnetic flow meter

3 division measurement type converter only available for remote type/ split type

3.7 calibration setting

System calibration setting same as basic type.

3.7.4 Time division measurement

1. Function

Generally energy flow has the period of peak, valley and normal, peak period the energy is not sufficient, and valley period is in surplus, under such circumstance, adopts peak valley and normal measurement mode. Peak: shows the total flow within the peak value during certain period; valley: shows the total flow within the valley value in the certain period; normal: total flow other than the peak and valley value. Peak, valley and normal flow are calculated individually, and can set the charging criteria according to different total flow value.

2. Setting

Enter the setting menu- mode- trading, choose time division " on" and confirm, go to time division measure setting, " peak" and "valley" each has 2 period available to set.

3. Display

3.8 Quantitative control type (please note when place order)

Quantitative control type electromagnetic flow meter converter combines flow, integrating and display, with the function of quantitative control. This meter is convenient for set the Quantitative flow value, remaining flow alarming value, also available to open or shut-off the valve under emergency, realize the function of quantitative control and monitor.

3.8.1 Function

Same function as basic type electromagnetic flow meter

3.8.2 Wiring

Same wiring as basic type electromagnetic flow meter, only add the wiring of quantitative control ON/OFF output of K11, K12, corresponding to terminal 21, 22

Quantitative control type converter only available for remote type/ split type

3.8.3 calibration setting

System calibration setting is same as basic type.

3.8.4 Quantitative control

1. Function and alarm setting

In set menu- mode- trading, select quantitative control " on" and confirm Go to quantitative control and set the alarm value, this value can't be bigger than Quantitative value, when quantitative value remaining value lower than this value, meter will send out quantitative control remaining value reach zero.

2. quantitative control charging

the quantitative alarm value and confirm, enter quantitative set, set the quantitative control value. This value can be set in the operation control menu instead of entering setting menu.

3. qualitative control

press right shift button enter menu of quantitative control, press right shift button for 3 seconds and adding button , can modify the value and press button to confirm this value, press shut off the relay, related valve open, then qualitative control starts. When the remaining values lower than the value, the alarm is on, until the relay disconnect, the related valve shut, the quantitative control end.

During this period, if need the relay disconnect, shut off the valve, can be realized by pressing button, when the emergency clear, restore the control, re-press the button

4. load capacity

load capacity Max 220Vac/5A, 30VDC/3A

3. Pre-paid quantitative control type (please note the place order)

Pre-paid quantitative control type electromagnetic flow meter converter combines flow, integrating and display, with the function of pre-set quantitative control. This meter is convenient for manual quantitative charging, manually set the flow unit price, quantitative value also available to open or shut-off the valve under emergency, realize the function of quantitative control and monitor.

3. Function

1. (heat) detection function same as basic type (heat type)

electromagnetic flow meter

3.8.2 Wiring

Same wiring as basic type (heat type)electromagnetic flow meter, only add the wiring of pre-paid quantitative control ON/OFF output of K11,K12, corresponding to terminal 21、 22

Quantitative control type converter only available for remote type/ split type

3.8.3 Calibration setting

System calibration setting is same as basic type.

3.8.4 Pre-paid quantitative control

1. Function and alarm setting

Enter set menu- mode- trading, select quantitative control " on" and confirm Go to quantitative control and setting, set the unit price(flow, heat unit price), quantitative alarm value and quantitative charging.

Make sure the value correct and confirm, press button for 3 seconds, hear the sound of "DI", press button to check the quantitative charge value turn Zero, it shows charging succeed.

Quit the setting, enter pre-paid quantitative control main menu, can check the flow (heat) remaining value and the balance.

2. Quantitative control

During the normal process, the switch control output is disconnected, when the balance is lower than the set the quantitative alarm value, the meter sends out BUZZ noise until the balance turn zero, switch output disconnect, related valve shut off.

3. load capacity

Relay load capacity Max 220Vac/5A, 30VDC/3A

4. Password Settings

1、 Press continuously for 3 seconds to input the password, level 1 password is for the users, factory default is "0000"; level II password is for the manufacturer , the factory default is "2222"

2、 To set a new password, please see "Parameter Settings" related content.

Levee 1112	Le ve 13	level 4	The parameter selection and range	Password classificati on	Applicable model
Medi um	/	Measure Medium	water/liquid	Password I	Universal
		Density compensatio n	Temperature compensation/D ensity setup		
		Flow Unit	m ³ /L/Kg		
		Heat Unit	KG/MJ/GJ/Kwh		Heat type
Init alup	/	Instantaneou s decimal	0 to 3	Password II	Universal
		Cumulative decimal:	0 to 3		
Model rec ion alup	/	/	Flow direction: Forward reverse Negative flow: ON/OFF	Password I	Universal
			Flow rate fiction		
			Suppression time		
			Filter constant		
Filter alup	/		1~30	Password II	Universal
Trade e	/	Protocol control	ON/OFF	Password II	Trade type
		Quantative control	ON/OFF		
			ON/OFF		
			ON/OFF		

Leve 11	Leve 12	Le ve 13	level 4	The parameter selection and range	Password classificati on	Applicable model
Para mete r	Dia me ter	/	/	3~3000mm	Password I	Universal
	Range upper limit	/	/	0~99999	Password I	Universal
	Range lower limit	/	/	0~99999	Password I	Universal
	Outp ut up limit	/	/	0~99999	Password I	Universal
	Outp ut low limit	/	/	0~99999	Password I	Universal
	Flow rate cut	/	/	0~1m/s	Password I	Universal
	Tempe rature upper limit			0~200°C	Password I	Heat type
	Tempe rature lower limit	/	/	0~200°C	Password I	Heat type
	Flow coeffic ient	/	/	0.0000~6.0000	Password II	Universal

Leaveve 1112	Le ve 13	level 4	The parameter selection and range	Password classificati on	Applicable model
low ate 1-5	/	/	0~1.0000m/s	Password III	Universal
Para atio meta 1-5			0.0000-2.0000	Password III	Universal
ero rim	/	/	0~±0.0300 v	Password III	Universal
ass ord	Pa ss wo rd1	/	0000-9999	Password I	Universal
	Pa ss wo rd2	/	0000-9999	Password II	Universal
Syste time m setup	/	/	Year-Month-Day Hour-Minute-Second	Password I	Universal
auto how	/	/	Flow / instantaneous / accumulated /total/output/ heat / temperature / stop	Password I	Universal

Leave 11	Leave 12	Le ve 13	level 4	The parameter selection and range	Password classificati on	Applicable model
	Outp ut setup	/	Output signal	Frequency(0~50 000Hz/ Pulse(pulse constant and width))	Password I	Universal
	Zero clear	/	/	Accumulative values clear / power off record clear / report clear	Password II	Universal
	Back light setup	/	Backlight Control	Always on / off	Password I	Universal
	Reco rd setup	/	Record interval	00 min	Password I	Universal
	Lang uage	tan gu ag e	/	Chinese/English	Password II	Universal
		Edi t	Forward total	0~99999999m³	Password II	Heat type
		Fa ult set tin g	Reverse total	0~99999999m³		
			Fault inlet temperature	0~150℃		

Leave 1 1 1 2	Level 1 3	level 4	The parameter selection and range	Password classification on	Applicable model
Language		Fault outlet temperature	0~150℃	Password II	Heat type
		Inlet tem move	0~150℃		
		outlet temperature	0~1000℃		
		Fault			
Unit	Editing	Forward accumulated : 0~9999999m ³ Reverse Cumulative : 0~9999999m ³		Password II	Universal
	Setting				
Communication / on	/	/	Native IP address: 0-999 Baud Rate : 1200n1~9600e1	Password I	Universal
Other settings	/	/	Serial number0~99999 999	Password II	Universal
Save /	/	/	Do you need save? Yes/No	Password I	Universal

IV Instrument detection and maintenance

Electromagnetic flow converter has self-diagnosis function. In addition to the power and hardware circuit fault, The system also give alarm to other faults in general usage. These information are given accordingly prompts in the lower right of the screen.

1、Maintenance and repair

a) Sensor installation site should be consistent with the section four requirements, Please keep the housing clean and tidy;

b) Transmitter should be placed in a clean, ventilated, dry place;

c) Need to inspect every two years, for high precision users, instrument need to be submitted to censorship.

2、Transportation, storage

a) The instrument must be packed before transportation, be carefully handled when loading and unloading.

b) Storage site must be dry, ventilated, avoid corrosive gas erosion, the ambient temperature is not too low or too high;

c) Storage time better not exceed three years.

3、Unpacking and checking

a) The packing can't be opened with heavy hammer, and should be careful not to damage the instrument

b) Check the content carefully according to the packing list.

4. Ble shooting

Fai	Fault diagnosis	Solution
Cover no display	1. lack of power supply	Check the power supply or if the
	2. converter fault	Change converter
Exon alarm	1. excitation terminal X and Y open	Check the excitation cable
	2. sensor excitation wire resistance too big	Change matching of the converter excitation current and sensor
Empty alarm	1. excitation current reverse	Change converter excitation terminal
	2. wrong signal cable connection	Check and correct signal cable connection
	3. measuring fluid does not contact the electrode	Change the installation of sensor, make fluid fully filled in the pipe
	4. actual flow direction reverse with indicated	Change the installation of sensor
	5. electrode signal short circuit	Signal cable insulation damaged
	6. no excitation current	Excitation cable damaged
	7. electrode covered by insulant material	Use multi-meter measure the voltage between A and B, it should be lower than 1V, if not , clean the electrode, remove the covering material
	8. low conductivity of the measuring fluid	Try to make converter signal terminal A,B,C short circuit
Instate meing data	1. wrong signal cable connection	Check and correct the signal cable connection

Fault	Fault diagnosis	Solution
Inaccurate measuring data	2. wrong transmitter setting	Re-set the parameter according to default setting
	3. the fluid is not fully filled in the pipe	Change the sensor installation, make the fluid fully filled in pipe
	4. the measuring fluid contains bubbles or oil	Eliminate bubbles or oil
	5. sensor grounding fault	Operate grounding properly
	6. electrode covered by insulant material	Cleat up the electrode
	7. unsteady power supply, strong interference	Change power supply or provide anti-interference power
	8. strong interference nearby	Change installation site, avoid interference
	9. share same grounding cable with other facility	Use individual grounding cable for sensor
	10. sensor grounding connected with converter casing	Cut off the connection, make the sensor grounding individual
	11. sensor grounding cable too long or too slim, cause to large grounding resistance	Make grounding point nearby , make the grounding resistance lower than 10 Ω
Converter display exceed the full scale(above 100%)	1. actual flow exceed the maximum flow range	Select the suitable flow meter according to actual flow range
	2. fluid half filled in pipe or even empty pipe	Change pipe or sensor's installation, to make sure fluid full pipe

#ft	Fault diagnosis	Solution
Cover display ex the full scabove 100%)	3. electrode covered with insulant material, such as oil, bubble etc. 4. signal cable short circuit	Clean the electrode Change the signal cable or make some screening or insulation.

DN	Flow value table in [m ³ /h]					
$f = 0.3 \text{ m/s}$	$V = 1 \text{ m/s}$	$V = 3 \text{ m/s}$	$V = 5 \text{ m/s}$	$V = 8 \text{ m/s}$	$V = 10 \text{ m/s}$	
10	0.085	0.283	0.848	1.414	2.287	2.827
20	0.339	1.131	3.393	5.655	9.243	11.810
25	0.530	1.767	5.301	8.836	14.137	17.871
32	0.868	2.885	8.686	14.478	23.432	29.693
40	1.357	4.524	13.572	22.619	36.191	45.239
50	2.121	7.069	21.206	35.343	56.729	71.883
65	3.584	11.946	35.838	59.729	84.887	107.463
80	5.429	18.096	54.287	90.478	141.78	180.82
100	8.482	28.274	84.823	141.37	228.18	282.74
125	13.254	44.179	132.54	220.89	363.43	441.787
150	18.085	63.617	190.85	318.087	508.49	636.17
200	33.929	113.10	339.30	565.48	843.78	1131.8
250	53.014	176.71	530.14	883.57	1413.7	1767.1
300	76.341	254.47	763.41	1272.3	2033.7	2544.7
350	103.90	346.36	1039.1	1731.8	2718.8	3463.6
400	135.72	452.39	1357.2	2261.9	3618.1	4523.9
500	212.06	706.86	2120.6	3534.3	5654.9	7068.6
600	305.36	1017.9	3053.6	5089.4	8443.0	10178.7
800	542.87	1809.6	5428.7	9047.8	14478.4	18092.5
1000	848.23	2827.4	8482.3	14137.1	22818.4	28274.3

Optimal flow 1 – to 5m/s

Warning

To ensure the products are capable of long-term use in the field, to bring you accurate measurements, you are forbidden to dismantle the product during the custody, installation and processing!

Thank you for your cooperation!

Nanjing Metran Measurement & Control Co., Ltd